

\*\*\*\*\*

Software for Positioning and Measurement  
About SGEMCS Ver4.01

June 20. 2008 SIGMA KOKI CO.,LTD. Technology Center

\*\*\*\*\*

Environment

◆Hardware

Personal computers with Windows95/98 (SE) /Me/2000/XP/Vista

CPU	:Pentium II 333MHz or more
Memory	:64MB or more (Recommend 128MB or more)
HardDisk	:More than 50MB free space
Drive	:CD-ROM or FD(Installation possible drive)

◆Software

OS	:Microsoft Windows95/98 (SE) /Me/2000/XP/Vista
Application	:Microsoft Excel97 or later

◆Interface

Please pay attention because there is restriction by the environment and devices etc. where it is used, although it is supporting the interfacing of RS232C/GPIB/USB in this product.

RS232C	:Standard correspondence.
GPIB	:GPIB is only supported for an interface board from National Instruments. Before using the GPIB interface, the device driver for the GPIB card must be installed.
USB	:USB control is supported for SHOT series only. Before using the USB interface, the device

driver for the SHOT series must be installed.

◆Others

We are doing action confirmation in the following environment.

Excel97/2000/2002/2003.

We are doing action confirmation by the following stage controller about the USB interface.

SHOT (Mark)-202/204, FINE (Mark)-501/502/503 series

The guarantee and also inquiry regarding the action of this product ask to cause in above environment limited.