
Software for Positioning and Measurement
About SGEMCS Ver6.06

October 14, 2014 SIGMA KOKI CO.,LTD. Technology Center

Environment

◆Hardware

Personal computers with WindowsXP/Vista/7 (32bit/64bit)

CPU	:Pentium4 1GHz or more
Memory	:512MB or more (Recommend 1GB or more)
HardDisk	:More than 50MB free space
Drive	:CD-ROM(Installation possible drive)

◆Software

OS	:Microsoft WindowsXP/Vista/7 (32bit/64bit)
Application	:Microsoft Excel97 or later

◆Interface

Please pay attention because there is restriction by the environment and devices etc. where it is used, although it is supporting the interfacing of RS232C/GPIB/USB in this product.

RS232C	:Standard correspondence.
GPIB	:GPIB is only supported for an interface board from National Instruments. Before using the GPIB interface, the device driver for the GPIB card must be installed.
USB	:USB control is supported for SHOT series only. Before using the USB interface, the device

driver for the SHOT series must be installed.
USB can be used in the personal computers with
Windows Vista/7 (32bit/64bit).

◆Others

We are doing action confirmation in the following environment.

Excel 97/2000/2002/2003.

We are doing action confirmation by the following stage controller
about the USB interface.

SHOT (Mark) -202/204/302/304, FINE (Mark) -501/502/503 series

The guarantee and also inquiry regarding the action of this product
ask to cause in above environment limited.